### Noah MidSleeper Reversible IMPORTANT READ CAREFULLY RETAIN FOR FUTURE REFERENCE

### Thank you for buying the Noah MidSleeper

- Please take a few minutes to read through these instructions before attempting to build this product
- Because of the size of this product we recommend that it is built in the room intended for use and that it
  is assembled by two adults
- As this product contains small parts please keep small children clear from the assembly area
- Carefully layout all the parts on a clean, flat surface and compare with the parts checklist. Save all
  packaging until assembly is complete to avoid accidentally discarding fittings

### PRODUCT SAFETY


- Recommended Mattress Size: 190cm x 90cm. The thickness should not exceed the line marked on the upper end
- Do not allow children to jump on the bunks. Using this furniture other than for its intended purpose could cause damage to the structure or serious injury to your child
- Be aware of the danger of young children (under 6) falling from the upper bunk
- We recommend that you periodically check and ensure that all components are in their proper position,
   free from damage, and that all fittings are fully tightened
- Before each usage or assembly, inspect bed for damaged hardware, loose joints, missing parts or sharp edges. Do not use bunk bed if any parts are missing or broken
- Always use the ladder for entering and leaving the upper bunk
- Never attach or hang items to any part of the bunk bed that are not designed for use with the bed
- Noah MidSleeper has passed BS EN 747-1&2:2012
- Children can strangle in items such as ropes stings cords harnesses and belts attached to bunk bed/high bed

Warning: Children can become trapped between the bed and the wall. To avoid risk of serious injury the distance between the top safety barrier and the wall shall not exceed 75mm or shall be more than 230mm.

Warning: "High beds and the upper bed of bunk beds are not suitable for children under six years due to the risk of injury from falls"


### **PRODUCT CARE**

- Wipe clean using a soft damp cloth followed by dry cloth
- Do not use abrasives or cleaning products which may contain ammonia or solvents
- Take Care when handling or moving the furniture. Careless handling can damage furniture, try to lift rather than drag
- TWO options of the Noah Midsleeper can be assembled(as below drawings)



### **TOOLS REQUIRED**


 Please use Philips Head Screwdriver (not included) and Allen key part 4, 9 (included) to assemble the Noah Midsleeper






ASSEMBLY INSTRUCTION Noah Midsleeper Reversible 10NOH5002 Page 1 of 8






ASSEMBLY INSTRUCTION Noah Midsleeper Reversible 10NOH5002 Page 3 of 8



ASSEMBLY INSTRUCTION Noah Midsleeper Reversible 10NOH5002 Page 4 of 8



# ASSEMBLY INSTRUCTION Noah Midsleeper Reversible 10NOH5002 Page 5 of 8

