

Bedrooms by
feather & black


Shoreditch

IMPORTANT READ CAREFULLY – RETAIN FOR FUTURE REFERENCE

THERE MAY BE A CABLE TIE ATTACHED TO THE UNDERNEATH OF YOUR SOFA BED TO ASSIST WITH TRANSPORTATION; PLEASE REMOVE THIS BEFORE ATTEMPTING TO OPEN THE SOFA BED

PRODUCT SAFETY

The following instructions for the opening and closing of your sofa bed should be followed to avoid the risk of possible finger entrapment.

- For your safety the  symbols on Image 1 identify areas to avoid placing your hands when opening and closing your sofa bed.
- NEVER allow children to play with or operate the fold-out bed actions.

PRODUCT CARE

- The Fabric on this product is Flame Retardant treated and therefore should be specialist upholstery cleaned only.
- Do not discard any of the packaging until you have checked the product.

OPENING & CLOSING OF YOUR SOFA BED

Your sofa bed may differ in look from the images shown but the mechanism will be the same.

1. From Sofa to Bed



PLACING YOUR HAND IN THE CENTRE OF THE FRONT PLINTH, GENTLY LIFT UP AND OVER THE BOTTOM LEDGE TOWARDS YOU



PULL OUT INTO BED POSITION



2. From Bed to Sofa



LIFT FRONT OF SOFA
BED UP UNTIL IT LOCKS
INTO PLACE

(AS SHOWN IN IMAGE)

NOW, PRESS DOWN TO
THE FLOOR AND PUSH.
BED WILL START TO
RETURN TO SOFA
POSITION



ONCE BACK IN SOFA
POSITION GENTLY LIFT
AND PUSH FRONT OF
PLINTH OVER BOTTOM
LEDGE TO LOCK INTO
PLACE