


# feather&black

## Casterton Dressing Table - Assembly Instruction

Product size

H80 x L45 x W122 cm



If you require any advice during assembly, please call our customer service team on  
01243 380600

**Please retain these assembly instructions for future use**

# feather&black

## Casterton Dressing Table - Assembly Instruction

### Before you start

Thank you for purchasing this Casterton Dressing Table.

Please read these instructions fully prior to assembly to familiarise yourself with the various stages of construction. Carefully open all packs supplied and check the contents against the parts and fittings check list.

Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

This item is heavy once assembled. Please try to assemble the item as close as possible to the point of use. Take care when moving the item to avoid personal injury or damage to the product and always lift rather than drag.

There are small components used in the construction of this furniture as well as plastic packaging, these should be kept away from young children whilst assembling.

#### Product Safety

All assembly fastenings should always be tightened properly, and care should be taken to ensure that no fittings are loose.

Periodically check and ensure that all components are in their proper position, free from damage, and that all connectors are tight.


Please note depending on the lighting, positioning and surroundings of your room, the shade of the colour can sometimes appear slightly different. Over a period of time the colour might lighten or fade slightly due to light exposure.

#### Product Care


To clean, slightly moisten cloth with water and wipe surfaces. A damp cloth holds dust and prevents damage. repeat with a dry, soft, lint-free cloth. Do not use abrasives or cleaning products which may contain ammonia or solvents.

#### Number of people required to assemble

One people to assemble the product and two people to lift in to position.




#### Time to assemble



1/2 Hour

#### Necessary tools




#### Missing parts or faulty products

If you are missing any fixtures or fittings during assembly, or a part is unfortunately faulty please call our customer service team on 01243380600

# feather&black

## Casterton Dressing Table - Assembly Instruction

Components supplied (not actual size)



- (1) : Top Table                      Qty : x 1 pc  
(2) : Legs Frame                      Qty : x 2 pcs

# feather&black

## Casterton Dressing Table - Assembly Instruction

### Fixtures and fittings supplied (not actual size)



(A) : Allen Bolt  
M6x35mm  
Qty : x 8



(B) : Spring Washer  
Ø14 x 2mm  
Qty : x 8




(C) : Flat Washer  
Ø18 x 2mm  
Qty : x 8



(D) : Allen Key  
Qty : x 2



(E) : Plastic Anchors  
(Ø4\*35mmL)  
Qty : x 4




(F) : Hanger tip kid  
Qty : x 4




(G) : Screw  
M4x35mm  
Qty : x 4



(H) : Screw  
M4x15mm  
Qty : x 4




(K) : Key brass  
Qty : x 2




# feather&black

## Casterton Dressing Table - Assembly Instruction

Step 1: Turn the block wood to unlock.




Step 2: Remove the drawer go out.




# feather&black

## Casterton Dressing Table - Assembly Instruction

**Step 3:** Place the table Top (1) upside down on a piece of cloth or carpet to prevent finish from scratching. Attach the Leg Frame (2) to the each corner of the Table Top (1) by using Spring washer (B) Flat washer (C), Allen Bolt (A) and fully tighten all Bolts by using Allen Key (D).




**Step 4:** Remove the drawer go in and turn the block wood to lock.




# feather&black

## Casterton Dressing Table - Assembly Instruction

Step 5:



Step 6:



# feather&black

## Casterton Dressing Table - Assembly Instruction

Step 7:

